


USER MANUAL

100proGreen Master Lawn Spiker Adapter for connection to Master Vario Drive Pro



1. Introduction of the Adapter

The adapter for the Master Lawn Spiker is a mounting adapter designed for connecting the Master Lawn Spiker machine to the Master Vario Drive Pro power unit. It serves as a structural intermediate component that enables a firm, precise, and safe mechanical connection between the two devices.

The adapter is designed exclusively for this specific combination of machines and replaces the original handle and transport components of the Master Lawn Spiker machine. Without the use of this adapter, it is not possible to connect the Master Lawn Spiker to the Master Vario Drive Pro power unit.

The adapter is designed as a fixed mounting component without its own drive wheels. It does not serve any load-bearing or transport function. Its purpose is to ensure the correct positioning of the machine relative to the power unit and to allow its smooth mechanical attachment.

Using the adapter significantly reduces the physical effort required from the operator during work. Thanks to the connection to the power unit, the Master Lawn Spiker does not need to be pushed or guided manually, which increases working comfort. This advantage applies both to the maintenance of larger lawn areas and to smaller gardens, where the operator will appreciate smoother machine guidance and reduced strain.

When properly installed, the adapter creates a stable connection without play and without any negative impact on the function of the working spikes (spoons). It thus enables safe and controlled operation of the entire assembly.

2. Installation and Commissioning

Always perform the installation of the adapter on a level, firm, and stable surface. Before starting the installation, make sure that the Master Lawn Spiker machine is secured against movement and that the working spikes (spoons) are not in contact with the floor or any other hard surface. Contact of the spikes with a hard surface may lead to their damage.

2.1 Machine Preparation

Place the Master Lawn Spiker on a suitable level surface so that it stands securely and there is no risk of tipping over. Pay special attention to the position of the working spikes. If necessary, support the machine frame with suitable material so that the spikes are protected during installation work. (We recommend a wooden beam or board.)

Before starting the installation, check that all mounting parts and fastening elements supplied with the adapter are available.

2.2 Removal of Original Parts


To install the adapter, it is necessary to remove the original control and transport components of the Master Lawn Spiker machine.

First, remove the machine handle and then remove the split transport rollers with the axle. The removed axle is no longer used after installation of the adapter.

2.3 Adapter Installation

Assemble the adapter together with the transport rollers into one complete unit as shown in the illustration. Use the newly supplied axle to fasten both parts together, which serves as a replacement for the original one. Insert the adapter with the transport rollers into the designated opening in the frame of the Master Lawn Spiker machine. Ensure correct orientation of the adapter and that it is evenly seated in the frame without tension.


Secure the adapter using the two supplied mounting bolts. Tighten the bolts gradually and evenly to ensure a firm and stable attachment of the adapter in the machine frame. Tighten with care to avoid damaging the threads or deforming the mounting points.



2.4 Connection of the Power Unit

After successful installation of the adapter, connect the Master Vario Drive Pro power unit. The connection must be made smoothly and without using excessive force. The power unit must fit correctly onto the adapter and lock securely into place.

If the locking does not occur, check the position of the adapter in the machine frame and adjust it slightly if necessary. After adjustment, try the connection again.



2.5 Pre-Operation Check

After completing the installation and connecting the power unit, perform a check of the entire assembly. Verify that all mounting bolts are securely tightened, the adapter is firmly fixed, and the connection to the power unit is free of play.

Check that the working spikes are not in contact with other parts of the machine and that the assembly is ready for safe operation.

3. Safety Instructions and Storage

3.1 Safety Instructions

The adapter is intended exclusively for connecting the Master Lawn Spiker machine to the Master Vario Drive Pro power unit. The product must not be used for purposes other than those intended by the manufacturer. Any other use is considered improper and may result in damage to the machine, the power unit, or hazardous situations.

Before starting installation, removal, or handling of the adapter, always secure the machine against movement. When working near the working spikes (spoons), wear protective gloves, as the spikes are sharp and there is a risk of injury.

The adapter is not subject to any modifications or structural changes. Do not use non-original fastening elements and do not make any alterations to the adapter design. All installation work must be carried out exclusively using the supplied or manufacturer-approved parts.

When connecting the power unit, do not use excessive force. If the unit cannot be connected or locked properly, check the position of the adapter and repeat the connection only after eliminating the cause.

Operating the machine with an incorrectly mounted or damaged adapter is prohibited.

3.2 Storage

Store the adapter in a dry and clean area, protected from moisture and weather conditions. Before storage, it is recommended to clean the adapter of dirt, soil residues, and grass.

During long-term storage, make sure that the adapter is not exposed to mechanical stress or deformation.

Before reuse after long-term storage, always check the condition of the adapter, especially the mounting points and contact surfaces, and ensure that they are not damaged or excessively worn.

4. Warranty

The adapter for the Master Lawn Spiker is covered by a 24-month warranty from the date of purchase, provided it is used in accordance with this manual and for its intended purpose.

The warranty does not cover damage caused by improper use, unprofessional installation, mechanical damage, use of non-original parts, or structural modifications.

All service and repair work should be entrusted to an authorized service center or the manufacturer. The use of non-original parts may result in loss of warranty.

5. Contacts



KONTAKTY:

Dovozce do ČR:

Zídekhhk s.r.o.
Václavské náměstí 823/33
110 00 Praha 1
Czech Republic

e-mail: info@zidekhhk.com
e-mail: info@100progreen.cz
Tel.: 00420 606 840 365
www.zidekhhk.com
www.100progreen.cz



Výrobce:

Christian Lechtenböhmer
100proGreen
Valentinstasse 177
45896 Gelsenkirchen
Germany